



TELEPHONE: (902)542-7478
FAX: (902)542-7479
e-mail: info@britcycle.com
website: www.britcycle.com

604 DAVISON STREET, RR3 WOLFVILLE, NOVA SCOTIA, B4P 2R3, CANADA
& 146 PORTER STREET, HACKENSACK, NEW JERSEY, 07601, USA

Fixing instructions for Tackyback Transfers

1. Remove the release paper
2. Locate transfer & squeegee firmly in position to remove air pockets
3. Thoroughly soak the transfer paper with water
4. Carefully remove the paper from the transfer
5. It is essential to wash the transfer thoroughly with clean water to remove surplus gum
6. The transfers can be put into service immediately but since any adhesive requires several days to achieve maximum bond we would not recommend pressure washing etc for at least 3 days. When cleaning with a pressure washer as with any self-adhesive product the nozzle should be kept a minimum of 600mm from the transfer.

NB The water must have completely penetrated the paper before removal is attempted, re-wet if necessary. If sufficient time is allowed the transfer paper will slide sideways with very little effort, indicating the paper is ready for removal.

Item 5 is essential!

For large transfers, a partial removal of the release paper, locating the transfer along one edge may prove easier.

IMPORTERS AND DISTRIBUTORS OF PARTS AND ACCESSORIES
FOR CLASSIC TRIUMPH, BSA AND NORTON MOTORCYCLES
HELPING TO KEEP BRITISH MOTORCYCLES ON THE ROAD SINCE 1977!
